


# How to Load a Project:




- 1 Type in your Job Number, or
- 2 Tap the camera icon to scan a barcode onsite.




# The Project Menu:

- 1 Lookup a New Project: Return to the Home Screen to look up a new project.
- 2 Reload Current Project: Pull down most recent data for the currently loaded project.
- 3 Clear All Loaded Projects: Clear data for all projects from device memory.
- 4 Recent Projects: Recall any of the (5) most recent projects.
- 5 Model Background: Change the background color to best suit your lighting conditions on site.






# Navigating the Model:






# Preset Model View Controls:

- 1 Return to Default Model View
- 2 Zoom extents maintaining current view angle
- 3 Zoom extents of selected objects






# Gridlines:



Quickly orient yourself to building layout by referencing labeled grid lines.



# Layer Controls:




- 1 Sheeting Parts (OFF)
- 2 Secondary Parts (ON)
- 3 Primary Parts (ON)
- 4 Grid Lines (OFF)




## Scanning Part Tags:

- 1 Tap the camera icon in bottom right corner to activate scan mode.
- 2 Bring the barcode into focus on the red line for an instant read.
- 3 A successful read will automatically select parts in the model.





# Manual Parts Search:



As an alternative to scanning barcodes, you can manually type in a part mark in the search field. Parts found will automatically be selected.



# Selection Tray:



- 1 Control visibility and see information about selected parts
- 2 Gather a running total weight for all selected parts before assembling sections on ground.



# Selection Tray:




- 1 Control visibility and see information about selected parts
- 2 Gather a running total weight for all selected parts before assembling sections on ground.



# Shipment Tray:

View contents of trucks and containers.

- 1 Expand/Collapse trucks, bundles, and crates to view contents






# Shipment Tray:

View contents of trucks and containers.


- 1 Select a part in the model and see it's source truck.





# Apply a Status:

- 1 Swipe the top ribbon of controls off to the side, to access Status Mode.
- 2 Tap the part(s) you want to status.
- 3 With the part(s) selected, tap the status color you want to apply.





## Connected vs. Offline:

An internet connection is required to:


- 1 Download a project for the first time.
- 2 Communicate statuses to the cloud (automatic, if connected).

All other functions work while offline.





# Manual Parts Search:



As an alternative to scanning barcodes, you can manually type in a part mark in the search field. Parts found will automatically be selected.